



SPEEDS & FEEDS

Elliott Monaghan Burnishing Speed guidelines



Elliott Monaghan Burnishing Feed guidelines



NOTE! When using 'Through' and 'Blind' series tools on automated machines, the feed must be set faster than the feed rate the helical cage achieves.